

## Instruction Manual – Equipment The Shore


### Safe



If the safe is locked and you cannot open it, please contact reception. To set the safe, follow these steps:

1. Check if the bolts are retracted in the safe door. If not, you can reset the safe. Inside the safe door, there is a black box with a button on the side. Press this button to reset the safe. An orange smiley will appear with a beep sound. Then, you can retract the bolts.
2. Select a 4-digit code and end your code with either **A** or **B**. You will hear a confirmation sound, and "OK" will appear on the display. You can now close the safe.
3. To reopen the safe, enter your chosen code with the corresponding letter **A** or **B**. The letter must match the one used when setting the code.

## Stove



- **Orange:** Power on/off button
- **Red:** Button to select the burner
- **Yellow:** Button for the ventilation
- **Green:** Button to adjust the temperature


1. Hold the power on/off button for 3 seconds until the other lights turn on to activate the stove.
2. Select a burner by pressing one of the four square buttons until you hear a beep.
3. Slide your finger from left to right on the bar to adjust the heat level of the burner. The heat levels range from 1 to 9, with a "boost" mode (b) for extra quick heating.
4. Press the ventilation button to turn on the fan. The ventilation strength is automatically adjusted.

## Dishwasher



- **Green:** Power on/off button
  - **Red:** Intensive program for heavily soiled dishes
  - **Orange:** Standard program for normal dishes
  - **Yellow:** Longer program using less water and energy
  - **Blue:** Quiet program
  - **Purple:** Program specifically for glassware
  - **Pink:** Short 1-hour program
  - **White:** Start button
1. Press the power on/off button.
  2. Select the desired program.
  3. Press start and close the dishwasher to begin the program.

## Air Conditioning




- **Red:** Mode button
- **Orange:** Fan speed button
- **Blue:** Power on/off button
- **Yellow:** Increase temperature button
- **Green:** Decrease temperature button

1. Turn on the air conditioning using the power button.
2. Select your mode.
3. Adjust the fan speed (air circulation intensity).
4. Set your desired temperature (24°C is 77°F).

**Note:** If the balcony doors are open, the air conditioner will show an error (filter check) and turn off.

## Combination Microwave/Oven









- **Function knob:** Use this knob to select the desired function.
- **Touch display:** Here, you can adjust weight, temperature, and start/stop settings.
- **Display:** Shows the selected program settings.
- **Setting knob:** Use this knob to adjust the settings shown on the display

### Display elements

Here you can find a short explanation of the various display elements.

Symbol	Name	Meaning
	Timer	If the symbol is highlighted, the timer appears in the display.
	Cooking time	If the symbol is highlighted, the cooking time appears in the display.
	Clock	If the symbol is highlighted, the clock appears in the display.
h:min	Hours/minutes	The time is displayed in hours and minutes.
min:sec	Minutes/seconds	The time is displayed in minutes and seconds.
	Childproof lock	If this symbol is highlighted, the childproof lock is activated.
	Rapid heating	If the symbol is highlighted, rapid heating is activated.
°C	Temperature	The temperature is displayed in °C.
kg	Weight	The weight is displayed in kg.

Symbol	Name	Temperature/levels	Use
	Microwave	Microwave power settings: <ul style="list-style-type: none"> <li>■ 90 W</li> <li>■ 180 W</li> <li>■ 360 W</li> <li>■ 600 W</li> <li>■ 900 W</li> </ul>	For defrosting, cooking and heating foods and liquids.
	Hot air	40 °C 100-230 °C	Let yeast dough rise, defrost cream cakes. For baking and roasting on one level.
	Hot air grilling	100-230 °C	Roasting poultry, whole fish and large pieces of meat.
	Plate warming	30-70 °C	Warming plates.
	Grill	Grill settings: <ul style="list-style-type: none"> <li>■ 1 = low</li> <li>■ 2 = medium</li> <li>■ 3 = high</li> </ul>	Grilling flat items such as steak and sausages, or making toast. Browning food.
	Programmes	-	There are preprogrammed settings for many dishes.